OrtisJet

## SOP of artisJet 3000U Pro (5000) setting-up

_			ABOUT			
About: This	is file is to guide the t	technicians or professional users to have quick printer settin	ng-up experience and avoid any e			
	4M1E	FROM ENDUSER		REQUEST FROM artisJet		REMAR
Man		1. PROFESSIONAL ENGINEER OR OPERATOR WITHA TECHNICIAN BACKGROUND. 2. TWO LABORERSWITH NECESSARY SECURITY PROTECTION(GLAVES/SAFTY SHOES).		1. ENGLISH-SPEAKINGENGINEER		
MACHINE 2. ATTA		PRINTER READY TO BE INSTALLED ATTACHED PACKAGE (WITHCARTTRIDGES, TOOLSAND SPAREPARTS RE READY) CHECKING.				
Material		POWER CABLE		1. PC WITHINTERNET 2. ON-LINE MEETING APPAND READY MEETING LINK 3. SUNLOGIN READY TO REMOTE CONTROL		
Метно	D			1. SOP OF ARTISJET P	RINTER SETTING-UP	
		1. CLOSE SPACE/ROOM 2. ENOUGH SPACE/>SOCM) AROUND THEPRINTER 3. POWER SUPPLY (110V/220V) 4. NORMAL WORKING ENVIRONMENT				
			SOP WORKF			
11		ON PRINTER	ON P		OPERATION DESCRIPTION confirm the schedule to hold the technical online	REMAR
	POINTMENT				supporting meeting	
2.1		PACKAGE INSPECTION UNPACK			check the package to make sure no damage remove the protective film	
2.3	HARDWARE	TAKE OUT& POSITION			take the machine out and position it on a solid	
					table/ printer packing box check the item and quantity of the standard	
2.4		STANDARD SPARE PARTS INSPECTION			configuration based on the " delivery information" file	
2.5		FINISH THE PACKING LIST QUESTIONNAIRE			Fulfill the questionnarire and send the copy back to go next step.	
2.6		REMOVE ALL THE TAPE			remove all the fixing tape both outside and inside	
2.7		CHECK THE PRINTER			confirm the tape removed on the carridge	
2.8		REPLACE THE EMPTY CARTRIDGES			pull the empty cartridges out (if sticked, try harder) from the cartridge holder	
201		INSERT INK CARTRIDES			ensure the color position is right and fully inserted into	
2.3 PF	REPAREATION				insert the waste ink cartridge (some printers are	
3.1		INSERT WASTE INK CARTRIDE			ready installed) and remove the rubber plug	
3.2		POWER CONNECTION			confirm the right power voltage and stability before action	
3.3		POWER ON			press the "Power" button on the right side	
3.4		CONTROL PANNELTESTING			Use Arrow Up-Down-Left and Right to move forward,backward, upward and downward printer table. Press Auto Position from printer for auto measurement.	
		PLACING MATT ON THE PLATFORM			Stick the Matt on working Table of Printer and remove the film from upside as well. Download and install the software following the	
3.1	SOFTWARE SETTING UP		INSTALL THE "SUNLOGIN"		guidance: https://sunlogin.oray.com/download/ share the DEVICE ID. and PASS CODE to artisJet Team	
3.2			EXIT THE ANTI-VIRUS AND DEFENCINGWALL/ FIREWALL		log out of the anti-virus software and firewall before install the printer driver. install the software in the flash disk following the	
			INSTALL "ARTISJET WORKSTATION5.0 V9 ( - VDP IS OPTIONAL VERSION)"		guidance (choose the 2 options at the last step is recommend) (accept and allow the installation, and add the "artisJet V 9.0" in to your trust list) . Demo video is on www. artisJet. xyz .	
3.4			INSTALL THE "VIRTUALPRINTER"		go to "Setting", follow the guidance from the pop-up installation window, and finish the installation. Demo video is on www.artisJet.xyz.	
			SET SOFTWARELANGUAGE(If needed)		click on the gear button on the bottom on the software and set the language. click on the gear button on the bottom on the	
3.5			SET THE SOFTWARE VER		software and set the printer model and version.	
4.1 4.2		DATA CABLE CONNECTION			connect the printer to PC insert the dongle into your printer server (PC)	
4.2 4.3	INITIALIZATION		INSERT THE DONGLE RUN THE "ARTISJET WORKSTATION"		double click the icon	
			INK CHARGING FOR INI		go to "PM" and select the "INK CHARGING"pull - down menu, select "Icfi" and click, then "Start" (6- 8mins)	
4.5			HEAD CLE	ANING	go to "PM" and select and perform the "Head	
		LOAD THE TESTING BOARD OR CARD TO			Cleaning"	
5.1		THE PLATFORM/ HUPPER				
5.2	NOZZLECHECK	AUTO PISITION		LE CHECK"	press the auto Position button on the printer	
5.2						
			PERFORM "NOZ		go to " PM" and select the " Nozzle Check" compare the pattern to the ones showed on WS/	
5.3 N			OR PATTERN		"service manual"to check the nozzle working condition	
5.3 N 5.4		CHECK THE COLOR PATTERN			If good, finish the process	