

Trouble-shooting for UV lamp goes out during printing

Q:When I print the lamp does not dry out the color and the lamp goes out

A:The 3000Upro, 5000U printers are water cooling mode for UV system. The antifreeze liquid is in lower level and UV lamp goes out due to high temperature protection program.

Add antifreeze liquid in time can avoid cooling pump, UV lamp damage.