



How to pack printer artis 5000U




1. Make sure the machine power cable is disconnected.



2. Empty waste ink bottle.




3. Remove all ink cartridges and insert soft tubes to the hole of ink cartridges.



4. Move carriage to the home position and fix carriage belt with tape tightly.



5. Fix the two acrylic covers with tape.



5. Pack printer with foam and plastic wrap, next place printer to wooden case.

