



artis proud

**Standard Accessory List and Non-accessory Parts**

**2021**

## ABOUT THIS FILE

This file introduces standard accessory list and non-accessory parts for artis Proud printer.

The non-accessory parts are consumable parts and customer will order it in future according to actual usage.

## CONTENTS

### Part 1 Standard Accessory parts




- 01 Power Cable
- 02 USB Cable
- 03 artisJet Workstation with USB Dongle
- 04 Dampers
- 05 Waste ink cartridges



### Part 2 Non-accessory parts

- 01 UV ink cartridges (CMYK)
- 02 Cleaning Liquid
- 03 Print Head Cables
- 04 Wiper
- 05 Captop
- 06 Grease
- 07 Non-Woven cloth
- 08 Gloves
- 09 Ink tubes
- 10 Reel paper
- 11 Electrostatic needle
- 12 Cleaning card

# 1


## Standard accessory list

Serial No.	Accessory Name	Photo	Remark
01	Power Cable (1pc)		There are three options : US Standard Plug, EU Standard Plug, UK standard Plug. Depends on the client's requirement or location.
02	USB Cable (1pc)		Connecting the printer with computer for print data transferring.
03	artisJet Workstation with USB Dongle		There is flash disk and USB dongle inside. The USB dongle is for using artisJet workstation without storage function.





04	Dampers (1pcs)		Consumable spare parts and not covered under warranty. Recommend to replace every 3 months.
05	Waste ink cartridges (2pcs)		Consumable spare parts. Recommend to replace in time. If use waste ink cartridges repeatedly, the waste ink level can not be recognized clearly.

## 2 Non-accessory parts

(non-accessory part, the quantity is according to order)

Serial No.o.	Accessory Name	Photo	Remark
01	UV Ink Cartridge		Consumable parts. (1 set with CMYK, single color is available)
02	Cleaning Liquid		Consumable part for cleaning ink tubes, print head nozzles.
03	Print Head Cables		Consumable spare parts. Recommend to replace if part is damaged.

04	Wiper		Consumable spare parts and not covered under warranty. Recommend to replace every 3 months.
05	Captop		Consumable spare parts and not covered under warranty. Recommend to replace every 6 months.
06	Grease (10ml/unit)		Tool for lubricating the carriage guiding bar for weekly maintenance.
07	Non-Woven cloth		Tool for daily, weekly, monthly maintenance.
08	Gloves (2pcs)		Tool for maintenance work.

09	Ink Tube (set)		Consumable spare parts and not covered under warranty. Recommend to replace every 10 months.
10	Reel Paper		Consumable spare parts and not covered under warranty. For bleeding
11	Electrostatic Needle		Consumable spare parts and not covered under warranty. Recommend to replace every 6 months.
12	Cleaning Card		Consumable spare parts and not covered under warranty. Recommend to clean the feeding wheels every month.





## PRODUCT CONSULTING



0086 158 1111 9658



proud@artisjet.com

## TECHNIAL SUPPORT



0086 138 1049 1878



mars@artisjet.com

## SAMPLE TESTING



0086 166 3208 9895



proud@artisjet.com