



How to pack printer Pro V6



1. Open front cover and fix carriage with double-sided tape.



2. Remove ink cartridges and waste ink cartridges. Insert ink holes with soft tubes.



3. Place printer into original package box. Lock four corners of printer.



4. Wrap printer with wrapping film.



5. Put protection bag to printer.



6. Pack ink cartridges and other spare parts to carton.



7. Lock four corners of outside package box.

