

artisJet proV6 How to print mother template position







ABOUT THIS FILE

Once E-fixture mat is out of service life, it can not keep sticky to position the mother template plate on flat table. This file is to introduce how to print mother template position after E-fixture mat replacement.

CONTENTS

内容

- 1. Open workstation
- 2. Replace new E-fixture mat
- 3. Import prn file to workstation
- 4. Position mother template on flat table







Open workstation and make sure USB cable is connected to printer.



OrtieJet Workstation for artisJet V6 V4.0 Beta												√4.0 Beta	
New job	Import Save Print	Cancel Delete	Setting P	M Preview									
#	State Job Title		b Title			Size	Copies	progress		3D Embossed	ASC	PD E	
<													
Job que	eue (3)				State	Print Mode		Output Size	Date Modified	Copies	Resolution	3D Embossed	Print Dire

Replace new E-fixture mat on flat table.

Take one piece of E-fixture mat and peel off the film Put the E-fixture mat onto the table and spread it till even on the surface









3 Import prn file to workstation.

Click Import option from workstation and import prn file(mother template positioning. Prn). Click Print to start printing.

查找范围(I):	artis Prov6 Installation file-C		•	
3称	^	修改日期	类型	
1-artisRIP	/9.0 Software & Workstation	2020/10/20 11:59	文件夹	
2-Installati	on Manual & videos	2020/10/20 12:00	文件夹	
3-Emojis&	Photos	2020/10/20 12:00	文件夹	
4-PRODUC	TS	2020/10/20 12:00	文件夹	Preview
5-PRN files	•	2020/10/20 12:00	文件夹	Now & Sotup
6-Tools		2020/10/20 12:00	文件夹	
			>	Option •
(件名(N):			打开(O)	
At NETHICT).	Tof File/# tof			

] color test.prn	
Color Test.tpf	
] Mother Template Positioning.prn	
Mother Template Positioning.tpf	

Ortis.	let							Worksta	ation for artisJet V6 V	4.0 Beta
New job	Import Save	Cancel Delete Setting PM Prev) ew							
#	State	Job Title		5	Size Copies	progress		3D Embossed	ASC	PD
<										
Job qu	ieue (2)									
lob Title	Joh Title			Print Mode	Output Size	Date Modified	Copies	Resolution	3D Embossed	Print C

Position mother template on flat table





Load the mother template to the printed position on the working table. Place the product template onto the mother template.











+86 158 1111 9658

info@artisjet.com

Technical Support

+86 186 1133 3892

ccc@artisjet.com

Sample Testing

+86 159 1024 3211

~

sample@artisjet.com

Daily Check Schedule for artisJet proV6