

Innovative brand in small sizes UV printers

2020

DAILY CHECK MANUAL

artisJet Young | artis 3000U pro | artis 5000U



ABOUT THIS FILE

Thank you for spending your valuable time on reading this file.

This file is vital to your experience and safety, as well as proper maneuvering of artisJet printers in production. The contents herein will guide you through the daily check procedures for the following artisJet cartridges printer models: artisJet Young A4 LED UV printer, artis 3000U pro B3 LED UV printer, and artis 5000U B2 LED UV printer.

The details herein introduce a daily check content, in two parts:

Part 1: At the beginning of each day;

Part 2: At the end of each day.

Please follow all the steps as instructed.





Daily check at the beginning of the day

DAILY CHECK AT THE BEGINNING OF THE DAY	
NO.	CONTENTS
1	Check to ensure that there is no jig currently on the printer's flat table.
2	Check to ensure printer is powered OFF. Carefully remove the white ink cartridges, one at a time.
3	While holding the rubber ink fill stopper, shake the white ink cartridges for 15 seconds.
4	 Check ink levels to ensure they are at least 40% full. If they are below 40%, please refill ink cartridge. <u>https://drive.google.com/drive/folders/12kqTrd-sw4QU_2Nw-P0DsdzZfyaA-kaF?usp=sharing</u> If the ink is running out in the ink cartridges (vacuum bag), please replace with new ink cartridges (vacuum bag). If ink cartridges were replaced, ensure that all are pushed all the way in and fixed. Plugging New Ink Cartridges <u>https://drive.google.com/drive/folders/1WbRBb7eIBD8KcpGE_0DTKj8tmPWINCIG?usp=sharing</u>
5	 Check and see if the waste ink bottle level / waste ink cartridge is above 70%. If so, remove the waste ink from the waste ink bottle. If there is waste ink cartridge, replace with new one. Waste ink cartridges replacement https://drive.google.com/drive/folders/1ilNfRjeRmyP60ErBpRs2sPT7ctvvodkU?usp=sharing
6	Power ON the printer, which will begin a self-checking process (1-2 minutes process)
Notice	After power on printer, if there is no self-checking process or error code appears on the screen, please contact artisJet support by ccc@artisjet.com



1



2 Daily check at the end of the day

DAILY CHECK AT THE END OF THE DAY	
NO.	CONTENTS
1	Press CLEAN button to perform head cleaning
2	Power OFF the printer by pressing the power button.







+86 158 1111 9658

info@artisjet.com

Technical Support

+86 186 1133 3892

ccc@artisjet.com

Sample Testing

+86 159 1024 3211

sample@artisjet.com